


SCHOTT is an international technology group with more than 125 years of experience in the areas of specialty glasses, materials and advanced technologies. With our high-qualitity products and intelligent solutions, we contribute to our customers' success and make SCHOTT part of everyone's life.

With a production capacity of more than 140,000 tons and production sites in Europe, South America and Asia, SCHOTT Tubing is one of the world's leading manufacturers of glass tubes, rods and profiles. Approximately 60 glass types are produced in large external diameters and a variety of lengths based on site-overlapping strategies in development, production and quality assurance. SCHOTT Tubing provides customized products and services for international growth markets such as pharmaceuticals and electronics as well as industrial and environmental engineering.

Contents



- 4–5 DURAN® Customer Service and Technical Consulting
- 6–16 Product Range
- 17–18 Physical and Chemical Properties
- 19–20 Tips on Processing
- 21 Packing

DURAN® Borosilicate Glass 3.3

Gives you an advantage in both quality and service



DURAN® in the Laboratory

- Highly resistant to thermal shock and heat
- Resistant to water, strong acids, alkali and saline solutions
- Fulfills all major standards
 (e. g. DIN ISO 3585 and ASTM E438 Type I, Class A)
- Established brand for glassblowing items in the laboratory sector

DURAN® for Lighting

- High optical and cosmetic quality, therefore no unwanted reflections or refractions
- Tight geometric tolerances allow for stable manufacturing processes and easy assembly
- Especially low thermal expansion, high resistance to thermal shock and high chemical resistance make it optimally suited for use in adverse conditions
- Can be tempered upon request (DURATAN®)





DURAN® for Engineered Systems and Plants

- A wide range of dimensions and variable lengths helps to reduce and/or eliminate the need for subsequent dilation or part assembly
- High geometrical accuracy and excellent optical properties allow easy assembly, high functionality in service and low levels of maintenance
- Exceptionally corrosion resistant, chemically inert and will not burn
- Longstanding glass know-how for engineered systems and plants (heat exchangers, ozone generators, chemical plant engineering)

Scientific Services

The Scientific Services department of SCHOTT is available to customers for all questions concerning glass properties, processing and the various applications of DURAN® tubing, rod and capillary.

Equipped with its own chemical and physics laboratories this team of qualified experts is optimally suited to handle any question.

This means that our customers do not just get innovative solutions regarding the glass itself but we can also provide valuable input and knowledge to help solve problems within existing manufacturing processes. All you have to do is ask!

Do you have a new product idea?

We have the know-how! Contact us!

Scientific Services

Our services at a glance:

- Problem solving analysis for manufacturing processes
- Technical Advice for specific applications
- Know-how transfer available through workshops and lectures

Direct contact:

Mr. Dr. Andre Petershans andre.petershans@schott.com

Ordering around the clock

DURAN® can be conveniently and easily ordered online around the clock. The comprehensive and secure login functions at www.schott.com/tubing/ecom make ordering easy. Stock of inventory, price transparency and anticipated delivery date are only some of the helpful functions available.

Further information and individual login data are available by phone +49 (0) 9633/80-100 or by email at customerservice.tubing@schott.com.



All dimensions shown in this brochure can be ordered online: www.schott.com/tubing/ecom

Outside Diameter	Wall Thickness	Weight per Tube Length approx. 1500 mm	Cartor Conten		Pallet	Load
\bigcirc	Ŏ,	Ö				
mm	mm	g		Weight approx. kg	Number of cartons	Weight approx. kg
3 ±0.14	0.7 ±0.04	17	941	16.0	27	432.0
4 ±0.14	0.8 ±0.04	27	555	15.0	36	540.0
5 ±0.14	0.8 ±0.04	35	343	12.0	45	540.0
6 ±0.14	1.0 ±0.04 1.5 ±0.08	53 71	245 211	13.0 15.0	36 36	468.0 540.0
7 ±0.14	1.0 ±0.04 1.5 ±0.08	63 87	190 172	12.0 15.0	45 36	540.0 540.0
8 ±0.14	1.0 ±0.04 1.5 ±0.08	74 102	149 147	11.0 15.0	45 36	495.0 540.0



Outside	Diameter	Wall Th	ickness	Weid	ght per Tube		Car	ton	P.	allet	Load
Outside	Diameter	vvuii 11	iickiicss		approx. 1500mr	n		tents	•	unce	Loud
(J	E	\mathbf{c}					7			
m	nm	m	m		g		Number of Tubes	Weight approx. kg	Num of ca		Weight approx. kg
9	±0.14	1.0 1.5	±0.04 ±0.08		84 118		119 119	10.0 14.0	45 36		450.0 504.0
10	±0.14	1.0 1.5 2.2	±0.04 ±0.08 ±0.12		95 134 180		95 90 56	9.0 12.0 10.0	45 45 45	,	405.0 540.0 450.0
11	±0.18	1.0 1.5 2.2	±0.04 ±0.10 ±0.12		105 150 203		86 73 42	9.0 11.0 8.5	45 45 45	<u>, </u>	405.0 495.0 382.5
12	±0.18	1.0 1.5 2.2	±0.04 ±0.10 ±0.12		116 165 226		130 67 42	15.0 11.0 9.5	35 45 45	5	525.0 495.0 427.5
13	±0.18	1.0 1.5 2.2	±0.04 ±0.10 ±0.12		126 181 250		119 55 36	15.0 10.0 9.0	35 45 45	5	525.0 450.0 405.0
14	±0.18	1.0 1.5 2.2	±0.04 ±0.10 ±0.12		137 197 273		110 46 30	15.0 9.0 8.2	35 45 45	5	525.0 405.0 369.0
15	±0.18	1.2 1.8 2.5	±0.05 ±0.09 ±0.13		174 250 328		86 56 25	15.0 14.0 8.2	35 35 45	,	525.0 490.0 369.0
16	±0.18	1.2 1.8 2.5	±0.05 ±0.09 ±0.13		187 268 354		81 49 25	15.0 13.1 8.8	35 35 45	;	525.0 458.5 396.0
17	±0.18	1.2 1.8 2.5	±0.05 ±0.09 ±0.13		199 287 381		75 49 25	15.0 14.0 9.5	35 35 45	;	525.0 490.0 427.5
18	±0.18	1.2 1.8 2.5	±0.05 ±0.09 ±0.13		212 306 407		66 49 20	14.0 15.0 8.1	35 35 45	5	490.0 525.0 364.5
19	±0.18	1.2 1.8 2.5	±0.05 ±0.09 ±0.13		224 325 433		63 42 36	14.0 13.7 15.6	35 35 35	,	490.0 479.5 546.0
20	±0.25	1.2 1.8 2.5	±0.05 ±0.10 ±0.15		237 344 460		55 36 20	13.0 12.4 9.2	35 35 45	5	455.0 434.0 414.0

Outside	Diameter	Wall Th	nickness		per Tube rox. 1500 mm	Car Cont		Pallet	Load
($\vec{\Box}$	E		<u>ů</u>			7		
m	nm	m	m	!	g	Number of Tubes	Weight approx. kg	Number of cartons	Weight approx. kg
22	±0.25	1.2 1.8 2.5	±0.05 ±0.10 ±0.15	26 38 51	32	42 30 30	11.0 11.5 15.4	35 35 35	385.0 402.5 539.0
24	±0.25	1.2 1.8 2.5	±0.05 ±0.10 ±0.15	28 42 56	.0	36 25 25	10.3 10.5 14.0	35 35 45	360.5 367.5 490.0
26	±0.25	1.4 2.0 2.8	±0.05 ±0.10 ±0.15	36 50 68	14	30 25 20	10.9 12.6 13.6	35 35 35	381.5 441.0 476.0
28	±0.25	1.4 2.0 2.8	±0.05 ±0.10 ±0.15	39 54 74	-6	25 20 20	9.8 11.0 14.8	35 35 35	343.0 385.0 518.0
30	±0.35	1.4 2.0 2.8	±0.08 ±0.10 ±0.15	42 58 80	8	36 16 16	15.2 9.4 12.8	20 35 35	304.0 329.0 448.0
32	±0.35	1.4 2.0 2.8	±0.08 ±0.10 ±0.15	45 63 85	0	25 16 16	11.3 10.1 13.8	20 35 35	226.0 353.5 483.0
33	±0.35	2.0	±0.10	65	1	25	16.2	20	324.0
34	±0.35	1.4 2.0 2.8	±0.08 ±0.10 ±0.15	47 67 91	2	25 16 16	12.1 10.8 14.8	20 35 35	242.0 378.0 518.0
36	±0.40	1.4 2.0 2.8	±0.08 ±0.10 ±0.15	50 71 97	4	25 25 12	12.6 18.0 11.7	20 20 35	252.0 360.0 409.5
38	±0.40	1.4 2.0 2.8	±0.08 ±0.10 ±0.15	53 75 1 03	6	20 20 9	10.8 15.0 9.4	20 20 35	216.0 300.0 329.0
40	±0.55	1.6 2.3 3.2 5.0	±0.08 ±0.12 ±0.20 ±0.40	64 91 1 23 1 83	1 7	16 16 9 9	10.2 14.6 11.2 16.5	20 20 35 28	204.0 292.0 392.0 462.0
42	±0.55	1.6 2.3 3.2	±0.08 ±0.12 ±0.20	67 95 1 30	9	16 16 9	10.9 15.3 11.7	20 20 35	218.0 306.0 409.5

Outside Diameter	Wall Thickness	Weight per Tube Length approx. 1500 mm	Carton Contents	Pallet Load
\bigcirc	Ŏ,	Ö		
mm	mm	g	Number Weight of Tubes approx. kg	Number Weight of cartons approx. kg
44 ±0.55	1.6 ±0.08 2.3 ±0.12 3.2 ±0.20	713 1 007 1 371	16 11.4 16 16.0 9 12.4	20 228.0 20 320.0 35 434.0
45 ±0.65	5.0 ±0.40	2 101	9 18.9	28 529.2
46 ±0.65	1.6 ±0.08 2.3 ±0.12 3.2 ±0.20	746 1 056 1 439	16 11.9 9 9.5 9 13.0	20 238.0 35 332.5 35 455.0
48 ±0.65	1.6 ±0.08 2.3 ±0.12 3.2 ±0.20	780 1 104 1 506	16 12.4 16 17.6 6 9.0	20 248.0 20 352.0 35 315.0





Outside Diameter	Wall Thickness	Weight per Tube Length approx. 1500 mm	Carton Contents	Pallet Load
\bigcirc	Ŏ,			
mm	mm	g	Number Weight of Tubes approx. kg	Number Weight of cartons approx. kg
50 ±0.70	1.8 ±0.12	911	12 10.9	20 218.0
	2.5 ±0.15	1 247	12 15.0	20 300.0
	3.5 ±0.25	1 709	12 20.5	20 410.0
	5.0 ±0.30	2 363	6 14.1	35 493.5
	7.0 ±0.50	3 161	6 19.0	28 532.0
	9.0 ±0.65	3 876	6 23.2	21 487.2
52 ±0.70	1.8 ±0.12	949	9 8.5	20 170.0
	2.5 ±0.18	1 300	9 11.7	20 234.0
	3.5 ±0.25	1 783	9 16.0	20 320.0
54 ±0.70	1.8 ±0.12	987	9 8.9	20 178.0
	2.5 ±0.18	1 352	9 12.2	20 244.0
	3.5 ±0.25	1 856	9 16.7	20 334.0
55 ±0.70	5.0 ±0.35	2 626	4 10.5	35 367.5
56 ±0.70	1.8 ±0.12	1 025	9 9.2	20 184.0
	2.5 ±0.18	1 405	9 12.6	20 252.0
	3.5 ±0.25	1 930	9 17.5	20 350.0
58 ±0.70	1.8 ±0.12	1 063	9 9.6	20 192.0
	2.5 ±0.18	1 457	9 13.1	20 262.0
	3.5 ±0.25	2 004	9 18.0	20 360.0

Outside	Diameter	Wall Thicl	kness		ht per Tube approx. 1500mn	n	Carto		Pal	let Lo	oad
5	\vec{D}	Ŏ [*])		Ĝ			7	ۯ		
m	ım	mm			g		mber Tubes	Weight approx. kg	Number of carte	er V ons a	Veight approx. kg
60	±0.80	3.2 ±4 4.2 ±6 5.0 ±6 7.0 ±6	0.18 0.20 0.30 0.35 0.50 0.65	1 2 2 3	336 910 462 888 897 821		9 9 4 4 4 4	12.0 17.2 9,8 11.5 15.6 19.3	20 20 35 35 35 28	3 3 4 5	240.0 344.0 343.0 402.5 546.0 540.4
65	±0.80	3.2 ± 4.2 ±	0.18 0.20 0.30 0.35	2	451 077 682 151		8 4 4 4	11.7 8,3 10.7 12.6	20 35 35 35	2	234.0 290.5 374.5 141.0
70	±0.90	3.2 ±4 4.2 ±4 5.0 ±4 7.0 ±	0.18 0.20 0.30 0.35 0.50 0.65	2 2 3 4	567 245 903 414 632 766		8 4 4 4 4	12.5 9.0 11.6 13.6 18.5 23.1	15 35 35 35 35 21	3 4 4 6	87.5 315.0 406.0 476.0 547.5 485.1
75	±0.90	3.2 ± 4.2 ±	0.18 0.20 0.30 0.35	2	682 413 123 676		8 4 4 4	13.5 9.7 12.5 14.7	15 20 20 20	1 2	202.5 94.0 250.0 294.0
80	±1.20	3.5 ± 5.0 ±	0.18 0.25 0.40 0.70	2	035 812 939 712		4 4 4 4	8.2 11.3 15.8 26.8	20 20 20 20	3	64.0 226.0 316.0 536.0
85	±1.20	3.5 ±	0.18 0.25 0.40	2	166 996 201		4 4 4	8.7 12.0 16.8	20 20 20	2	74.0 240.0 336.0
90	±1.20	3.5 ±0 5.0 ±0 7.0 ±0	0.18 0.25 0.40 0.50 0.70	3 4 6	298 180 464 102 657		4 4 4 3 3	9.2 12.7 17.9 18.3 23.0	20 20 20 15 15	2 3 2	84.0 254.0 358.0 274.5 345.0
95	±1.40	3.5 ±	0.18 0.25 0.40	3	429 364 726		4 4 4	9.7 13.4 18.9	20 20 20	2	94.0 268.0 378.0

Outside	Diameter	Wall Th	ickness	9	per Tube		Carton ontents	Pal	let Load
5	$\vec{\Box}$	E		<u></u>				[
m	nm	mı	m		g	Numb of Tub			
100	±1.40	2.5 3.0 3.5 5.0 7.0 9.0	±0.18 ±0.20 ±0.25 ±0.40 ±0.50 ±0.70	2 50 3 0. 3 5- 4 90 6 8 8 60	56 47 89 38	4 4 3 3 3 3	10.3 12.1 10.7 15.0 20.5 25.8	12 12	206.0 108.9 128.4 180.0 246.0 309.6
105	±1.50	3.0 5.0	±0.20 ±0.40	3 2 5 2		3 3	9.6 15.8	12 12	115.2 189.6
110	±1.50	3.0 5.0 7.0	±0.30 ±0.50 ±0.70	3 3 5 5 7 5	14	3 3 3	10.1 16.5 22.7	12 12 12	121.2 198.0 272.4
115	±1.50	3.0 5.0 7.0	±0.30 ±0.50 ±0.70	3 5. 5 7: 7 9:	77	4 2 2	14.1 11.6 15.9	9 15 15	126.9 174.0 238.5
120	±1.50	3.0 5.0 7.0 9.0	±0.30 ±0.50 ±0.70 ±0.90	3 66 6 0 8 30 10 4	39 08	4 2 2 2	14. <i>7</i> 12.1 16.6 21.0	15 15	132.3 181.5 249.0 315.0
125	±1.50	5.0 9.0	±0.50 ±0.90	6 3 10 9		2	12.6 21.9	15 15	189.0 328.5
130	±1.60	3.0 5.0 7.0 9.0	±0.30 ±0.50 ±0.70 ±0.90	4 00 6 50 9 00 11 4	65 43	4 2 2 2	16.0 13.1 18.1 22.9	9 15 15 15	144.0 196.5 271.5 343.5
135	±1.60	5.0 7.0	±0.50 ±0.70	6 8. 9 4		2 2	13.7 18.8	15 15	205.5 282.0
140	±1.70	3.0 5.0 7.0	±0.30 ±0.50 ±0.70	4 3 7 0 9 7	90	4 2 2	17.3 14.2 19.6	15	155.7 213.0 294.0
145	±1.70	5.0	±0.50	7 3.	52	2	14.7	15	220.5

Outside Diameter	Wall Thickness	Weight per Tube Length approx. 1500mm	Carton Content		allet Load
\bigcirc	Ŏ [*]	Ö			
mm	mm	g		Veight Numl pprox. kg of car	
150 ±1.80	3.0 ±0.30 5.0 ±0.50 7.0 ±0.70 9.0 ±0.90	4 632 7 615 10 514 13 329	2	9.3 12 15.2 12 21.0 12 26.7 12	182.4 252.0
155 ±1.80	5.0 ±0.50	7 877	2	15.8 12	189.6
160 ±1.80	5.0 ±0.50 7.0 ±0.80	8 140 11 249	-	16.3 12 22.5 12	
165 ±1.80	5.0 ±0.50 7.0 ±0.80	8 403 11 617	-	16.8 12 23.2 12	
170 ±1.80	5.0 ±0.50 7.0 ±0.80 9.0 ±1.00	8 665 11 984 15 219	2	17.3 12 24.0 12 15.2 20	288.0
180 ±2.00	5.0 ±0.50 7.0 ±0.80 9.0 ±1.10	9 190 12 720 16 165	' - '	9.2 20 12.7 20 16.2 20	254.0



Outside	Diameter	Wall Th	nickness	Weight per Length approx. 1		Carton ontents	Pallet	Load
(J	Ť	\mathbf{c}	Ö				
n	nm	m	m	g	Numl of Tub	oer Weight oes approx. I	Number kg of cartons	Weight approx. kg
190	±2.10	5.0 7.0	±0.50 ±0.80	9 716 13 455	1 1	9.7 13.5	20 20	194.0 270.0
200	±2.40	5.0 7.0 9.0	±0.80 ±1.00 ±1.20	10 241 14 190 18 055	1 1 1	10.2 14.2 18.1	20 20 20	204.0 284.0 362.0
215	±2.50	7.0 9.0	±1.10 ±1.20	15 293 19 473	1 1	15.3 19.5	9 9	137.7 175.5
225	±2.70	7.0 9.0	±1.10 ±1.30	16 028 20 418	1 1	16.0 20.4	9 9	144.0 183.6
240	±2.90	9.0	±1.30	21 836	1	21.8	9	196.2
250	±3.00	5.0 7.0 9.0	±0.80 ±1.10 ±1.30	12 867 17 866 22 782	1 1 1	12.9 17.9 22.8	9 9 9	116.1 161.1 205.2
270	±3.00	5.0 7.0 9.0	±0.80 ±1.10 ±1.30	13 917 19 337 24 672	1 1 1	13.9 19.3 24.7	9 9 9	125.1 173.7 222.3
300	±3.80	5.0 7.0 9.0	±0.80 ±1.20 ±1.40	15 492 21 542 27 508	1 1 1	15.5 21.5 27.5	9 9 9	139.5 193.5 247.5
315	±3.90	7.0 9.0	±1.20 ±1.40	22 645 28 926	1 1	22.6 28.9	9 9	203.4 260.1
325	±4.00	9.0 10.0	±1.40 ±1.40	29 871 33 085	1 1	29.9 33.0	4 9	119.6 297.0
350	±4.00	5.0	±0.80	18 118	1	18.1	4	72.4
365	±4.50	7.0	±1.40	26 321	1	26.3	4	105.2
400	±5.00	6.0	±1.50	24 829	1	24.8	4	99.2
415	±5.00	7.0	±1.50	29 997	1	30.0	4	120.0
420	±5.00	10.0	±2.00	43 063	1	43.1	4	172.4


Standard length: 1500 mm

Special lengths of tubing (depending on outside diameter and wall thickness) are available upon request between 1000 and 10000 mm.

Glass cut to a length of 0.3 mm and longer available on inquiry.

DURAN® Capillary

	tside neter		ide neter	Weight per Tube Length approx. 1500 mm		rton tents
(j	ϵ	\ni	Ö	8	
m	ım	m	m	g	Number of Tubes	Weight approx. kg
4	±0.18	8.0	±0.08	40	250	10.0
5	±0.18	0.4 0.6 0.8 1.2	±0.08 ±0.08 ±0.08	65 65 64 62	154 154 156 161	10.0 10.0 10.0 10.0
6	±0.18	0.4 0.8 1.2 1.7 2.2 2.7	±0.08 ±0.08 ±0.10 ±0.10 ±0.10	94 93 91 87 82 75	104 108 110 115 122 133	10.0 10.0 10.0 10.0 10.0 10.0
7	±0.20	0.8 1.2 1.7 2.2 2.7 3.0	±0.08 ±0.10 ±0.10 ±0.10 ±0.10	127 125 121 116 110 105	79 80 83 86 91 95	10.0 10.0 10.0 10.0 10.0 10.0
8	±0.20	0.8 1.2 1.7 2.2 2.7 3.0	±0.08 ±0.10 ±0.10 ±0.10 ±0.10	166 164 160 155 149 144	60 61 63 65 67	10.0 10.0 10.0 10.0 10.0 10.0
9	±0.20	0.8 1.2 1.7 2.2 2.7 3.0	±0.08 ±0.10 ±0.10 ±0.10 ±0.10	211 209 205 200 194 189	47 48 49 50 52 53	10.0 10.0 10.0 10.0 10.0 10.0





Quantity of capillaries per pallet:

Number of cartons: 55 Weight: ca. 550.0 kg

Standard length: 1500 mm

DURAN®

Rod

Dian	neter	Weight / Length Length approx. 1500 mm		rton itents	Palle	t Load
		Ĝ	æ			
mı	m	g	Number of Rods	Weight approx. k	Number g of cartons	Weight approx. kg
3	±0.14	24	529	12.5	44	550.0
4	±0.14	42	298	12.5	44	550.0
5	±0.14	66	183	12.0	44	528.0
6	±0.14	95	140	13.2	44	580.8
7	±0.14	129	98	12.6	44	554.4
8	±0.20	168	80	13.4	44	589.6
9	±0.20	213	63	13.4	44	589.6
10	±0.20	263	45	11.8	44	519.2
12	±0.20	378	35	13.2	44	580.8
14	±0.30	515	24	12.4	44	545.6
16	±0.30	672	20	13.4	36	482.4
18	±0.40	851	20	17.0	27	459.0
20	±0.40	1 050	16	16.8	27	453.6
22	±0.45	1 271	12	15.3	36	550.8
24	±0.45	1 512	12	18.2	27	491.4
26	±0.55	1 775	9	16.0	27	432.0
28	±0.80	2 059	9	18.5	27	449.5
30	±0.80	2 363	6	14.2	36	511.2



Standard length: 1500 mm

DURAN® Borosilicate Glass 3.3 Physical and Chemical Properties


Physical Properties		
Coefficient of mean linear thermal expansion α (20 °C; 30	00°C) acc. to DIN ISO 7991	3.3 ⋅ 10 ⁻⁶ K ⁻¹
Transformation temperature T_g		525°C
Temperature of the glass at viscosity η in dPa \cdot s:	10 ¹³ (annealing point) 10 ^{7.6} (softening point) 10 ⁴ (working point)	560°C 825°C 1260°C
Density ρ at 25 °C		2.23 g ⋅ cm ⁻³
Modulus of elasticity E (Young's modulus)		63 ⋅ 10³ N ⋅ mm ⁻²
Poisson's ratio μ		0.20
Thermal Conductivity λ_w at 90 °C		1.2 W ⋅ m ⁻¹ ⋅ K ⁻¹
Temperature for the specific electrical resistance of 108 Ω	· cm (DIN 52 326) t _{k 100}	250°C
Logarithm of the electric volume resistivity ($\Omega \cdot \text{cm}$)	at 250°C at 350°C	8 6.5
Dielectric properties (1 MHz, 25 °C)	Dielectric constant (permittivity) ϵ Dielectric loss factor (dissipation factor) tan δ	4.6 37 · 10 ⁻⁴
Refractive index ($\lambda = 587.6 \text{nm}$) n_d		1.473
Stress-optical coefficient (DIN 52 314) K		4.0 · 10 ⁻⁶ mm ² · N ⁻¹

Chemical Composition			
SiO ₂	B_2O_3	$Na_2O + K_2O$	Al ₂ O ₃
81	13	4	2

main components in approx. weight %

DURAN® Borosilicate Glass 3.3 Physical and Chemical Properties

Chemical Resistance	
Hydrolytic Class (DIN ISO 719)	HGB 1
Acid Class (DIN 12116)	Class S 1
Alkali Class (DIN ISO 695)	Class A 2



DURAN® Borosilicate Glass 3.3 is highly resistant to water, neutral and acid solutions, concentrated acids and acid mixtures; as well as chlorine, bromine, iodine and organic substances. Hydrofluoric acid, hot phosphoric acid and alkaline solutions do attack the glass surface but this is dependent on their concentration and temperature. Therefore, with these chemicals the use of DURAN® should be checked for each individual case.

DURAN® Borosilicate Glass 3.3 Tips on Processing

The excellent properties of DURAN® tubing, rod and capillary provide for good workability when forming and cutting the glass when using the normal techniques associated with technical glass.

Stress-free Annealing

To eliminate temporary stress as a result of the working process, the glass should be well heated to a maximum temperature of 550 °C and kept at this level for a maximum of 30 minutes. For a thinner wall only a fraction of this period is necessary. The chart below states the recommended cooling rate for the subsequent annealing:

Wall Thickness		Temperature Range	
in mm	550 to 480°C	480 to 400°C	400 to 20°C
3	~12°C/min	~ 24 °C/min	up to ~480°C/min
6	~3°C/min	~6°C/min	up to ~120°C/min
12	~0.8°C/min	~1.6°C/min	up to ~32°C/min

If an article needs to be annealed several times, the sum of all annealing periods at 550 °C should not exceed 2 hours.

Resistance to Thermal Shock

According to DIN ISO 718, resistance to thermal shock is the difference in temperature between the hot test sample and the cold water bath (room temperature) at which 50% of all test samples show a tendency to crack when quickly immersed. Listed below are some benchmarks to illustrate the resistance to thermal shock of tubing, rod and capillary made from DURAN® Borosilicate glass 3.3.

Tubes	Rod
OD 50.5/WT 5.00mm: ~220°C	Diameter 24.0 mm: ~140 °C
OD 133.0/WT 7.00mm: ~180°C	
OD 120.0/WT 8.00mm: ~180°C	

The resistance of tubing and rod to thermal shock depends on many different factors. Some of these are the wall thickness, shape and size of the chilled surface, the state of the surface, the stress already present in the glass, and the end finish. It is recommended not to exceed a temperature difference of 120°C.

DURAN® Borosilicate Glass 3.3

Tips on Processing

Pressure Resistance of Tubing made of DURAN®
Borosilicate Glass 3.3

The following formulas apply to stress-free tubing and cylindrical hollow bodies with a circular profile, uniform wall thickness with open ends, free from thermal load, under internal positive pressure and external negative pressure.

Calculation of Pressure Resistance (p)

$$p = \frac{WT \cdot 20 \cdot \frac{K}{S}}{OD - WT}$$

Calculation of the Wall Thickness (WT)

$$WT = \frac{OD \cdot p}{20 \cdot \frac{K}{S} + p}$$

OD = Outside Diameter in mm

WT = Wall Thickness in mm

p = Pressure Resistance in bar

Other points to be considered:


- AD 2000-leaflet N 4, edition 2000-10:
 Pressure vessels made of glass, with encl. 1, edition 2000-10:
 Evaluation of faults in walls of glass pressure containers
- AD 2000-leaflet B 1, edition 2000-10:
 Cylindrical and spherical shells under internal pressure overload

According to DIN EN 1595 "Pressure Equipment made from Borosilicate Glass 3.3 – General Rules for Design, Manufacture and Testing", DURAN® is an approved material and may be used for the construction of pressure equipment.

DURAN® Borosilicate Glass 3.3

Packing

Standard: Cartons Available upon request: DENSOPACK® (up to Outside Diameter 50 mm) DENSOPACK®
Tightly packed and covered with shrink film = effective transport protection



Technical Terms of Supply

Detailed information on permissible faults, definition of faults, testing methods and testing units are available upon request. Reduced tolerances are also available upon request. In case of quality complaints the relevant "Technical Terms of Supply" for the application apply to all sales and are binding unless separate written agreements with respect to quality have been entered into.

SCHOTT®, DURATAN® and DENSOPACK® are registered trademarks of SCHOTT. DURAN® is a registered trademark of the Duran Group GmbH.

Subject to technical alterations.

We thank our customers and partners for their kind assistance in providing product samples and photos.

Notes

Tubing
SCHOTT AG
Erich-Schott-Strasse 14
95666 Mitterteich
Germany
Phone +49 (0)9633/80-0
Fax +49 (0)9633/80-614
info.tubing@schott.com
www.schott.com/tubing